

Probe Temperature Sensor

Probe temperature sensor, Pt100
passive sensor in hazardous locations zones 1, 2 and 22

Type TFT-2G3D
ATEX compliant **Type TFT-VA-2G3D**

APPLICATION

TFT-(VA)-2G3D probe sensors for measuring temperatures. In combination with Ex-i transducer Type EXL-IMU-1 with intrinsic safe circuit the sensor may be used in hazardous areas 1, 2 and 22. The passive potential free resistor output of Pt100 sensor is changed into an active signal of 0(2)... 10 V- and/or 0(4)... 20 mA. Applications area is non condense, aggressive air in ducts, in plants as well as industrial areas.

TFT-2G3D / 100 mm	100 mm brass thermowell, Pt100	057.1220.01
TFT-V4A-2G3D / 200 mm	200 mm V4A thermowell, Pt100	057.1221.01
TFT-V4A-2G3D / 100 mm	100 mm V4A thermowell, Pt100	057.1222.01
TFT-2G3D / Pt100 / 100 mm	100 mm brass Ni plated Pt1000	057.1223.01
TFT-V4A-2G3D / 150 mm	150 mm V4A thermowell, Pt100	057.1224.01

TECHNICAL DATAS

Type	TFT-(VA)-2G3D
Supply	by Ex-i transducer
Sensor	Pt100 DIN, others on request
Thermowell	Brass or Stainless steel (VA) / L= length on request
Process connection	Threat G1/2
Accuracy	Class B
Sensor current	< 2 mA
Ambient temperature	Ta = -30...+60 °C
Measure temperature	Tb = -30... +150 °C
Storage temperature	-40...+70 °C
Connection	screw clamps 0,14 - 1,5 mm ²
Enclosure	Plastic, IP65 acc. to EN 60529
Dimension and weight	68 x 58 x 35 mm, approx. 150 g
Protection class	simple apparatus acc. to EN 60079-11
Temperature Class	T6 (max. 85 °C)
CE	94/9/EC (ATEX)
Includes in price	1 probe temperature sensor, Type TFT-(VA)-2G3D
Installation area	Hazardous locations in zone 1, 2 and 22

suitable for
Zone 1, 2, 22
acc. to ATEX



Ex-i CIRCUITS

Operation values maximum at terminal
Simple apparatus suitable for Zone 1, 2 and 22
Only for connecting to intrinsically safe circuits with max values

Voltage	Uo	10 VDC
Current	Io	10 mA
Power	Po	15 mW
Capacity	Ci	0 µF
Inductivity	Li	0 mH

The maximum values must not be exceeded!
Please check your external capacities and inductivities in acc. to the length of the cable and the methode of installation.

MOUNTING AND INSTALLATION


Notes to mechanical installation. The installation must comply with relevant directives and standards Particularly with regard to:
- Comply with the EMC directive
- Avoid parallel wiring of power cable this cause measurement errors.
- Recommendation: Use shielded cable. Connect shield at PLC or control room area, sensor side is open.
- permitted pressure, flow velocity
- choose fitting length and installation depth in such way that failures caused by heat abstraction keep small and the maximum ambient temperature are not reached

RECOMMENDED TRANSDUCER


- Transducer Mfr. Schischek Type EXL-IMU-1.
- In combination with transducer EXL-IMU-1 is intrinsic safety proof for simple circuits given.
- Manufacturer declaration zone 1, 2 and 22.

ELECTRICAL CONNECTION

Temperature Sensor TFT-2G3D



DIMENSIONS



ATTENTION!

- For installation, use and maintenance the official standards and rules must be applied.
- The energy of intrinsically safe circuits are below the level to start an explosion in case of a spark..
- Intrinsic safe circuits must be installed with light blue coloured and separate from non intrinsic safe circuits.
- The sensor is passiv and potential free for use in hazardous locations in zone 1, 2 and 22.
- Pay attention to the max values for wiring , listed in table 1.
- Avoid electrostatic discharge.
- Only wet cleaning.
- After mounting the protection class IP65 acc. to EN 60529 must be fulfilled

Subject to change
19-Okt-2012